

For items  
up to  
**5"**  
(12.7cm)  
wide

## Warranty Information

Xyron, Inc. warrants that the Xyron® 5" create-a-sticker™ is free from defects in material and workmanship for a period of one (1) year from the date of purchase. Xyron, Inc. will repair or replace a defective product or part without charge, provided it is returned to the address below, freight prepaid with proof of purchase. If the product is damaged by neglect or misuse, the warranty is null and void.

To register your product online, please go to [www.xyron.com](http://www.xyron.com) and click on the product registration tab. **If you register online, we will send you a free inspirational DVD full of great ideas!**

## Customer Service

We want you to be happy with your purchase of a Xyron product. If for any reason you have a problem or a question, we would like to hear from you before you consider returning it to the store where you bought it. In many cases, we will be able to solve your problem or answer your question right over the phone; so please contact Xyron Customer Service toll-free at **1-800-793-3523** or **1-480-443-9419** for help. You can also e-mail us at: [customerservice@xyron.com](mailto:customerservice@xyron.com)

### For customer service outside of the U.S.

Australia: 61 2 8899 8500; [australiacustomers@esselte.com](mailto:australiacustomers@esselte.com)  
New Zealand: 64 9 272 1600; [nzcustomers@esselte.com](mailto:nzcustomers@esselte.com)

The purchase or acquisition of this product does not confer the right or license to use the machine and cartridges in the retroreflective field or to make or sell machines or cartridges for use in the retroreflective field. U.S. patent numbers 5580417, 5735998, 5961779, 6244322, 6270612, 6403185, 6422281, 6660120, 7087280, 7104280, 7104304. Other U.S. and foreign patents pending.

©2008 Xyron, Inc.  
8465 N. 90th St. Suite 6  
Pima Center  
Soctsdale, AZ 85258

Visit [www.xyron.com](http://www.xyron.com) for more information and great project ideas

Part# 5715\_RevB

An  Company



 **XYRON®**

5" create-a-sticker™  
User Guide

For scrapbooking, crafts, special projects, and loads of fun... create-a-sticker™!!!

Never before has there been a machine that, without heat, batteries or electricity, applies an even layer of adhesive to the back of all kinds of materials up to 5" wide, including paper, photos, fabric, leather and more. It's safe and easy enough for kids to use and also a fun tool, which will help enhance your creative output. Say "good-bye" to messy glue sticks, liquid glues, spray glues, etc... and let your creativity soar with Xyron's create-a-sticker products.

Xyron adhesives are Acid-Free, Non-Toxic and safe for scrapbooking and other archival projects.

### Available Cartridges:



**Permanent Adhesive**  
Strongest hold  
For difficult surfaces

**Perfect for:**  
Photos, paper crafts, scrapbooking, card making, school and home projects, home décor, vellum, rubber stamping, and fabric, ribbon, metal and other 3-dimensional items



**Repositionable Adhesive**  
Reposition multiple times  
Best on smooth surfaces  
Stick it. Unstick it. Restick it.  
Safe for windows, painted walls, doors.  
Does not leave residue on most surfaces.  
Test in an inconspicuous area first.

**Perfect for:**  
Kid's stickers, paper crafts, scrapbooking, card making, school and home projects, stenciling, vellum, games, and photos

# Features & Functions

Adhesive Cartridge:  
Acid-Free Permanent  
or Repositionable  
refills available


Latch: Opens machine

Tear Bar: Cuts paper  
liner in a pull-up and tear  
across motion.

Feed Tray: Used to  
feed items into machine

Knob: Advances  
items through  
machine when  
turned clockwise.

Output tray: Where item  
exits machine.



# How to Change the Cartridges

## Unloading



1. Open cartridge compartment by lifting up on latch.

2. Gently pull cartridge up and out of machine.

3. You can unload/load the cartridge even though it may not be completely used.

## Loading



1. Guide cartridge into machine using tracks on machine sides.

2. Close lid by pressing down on latch until it clicks into position.

3. Advance material slightly to assure perfect results.

## Helpful Hints

- For best results, turn the handle slowly.
- Burnish or rub around your item well before removing from liner.
- Arrange small items (without overlapping them) on the feed tray to maximize your cartridge material use.
- Use items that are about the thickness of a nickel (1/16") or less.
- If there is excess adhesive around edges of an item, simply wipe off with your fingers. The adhesive comes right off without sticking to your hands.
- Fabric Tips:
  - Works well with most fabrics that do not have sizing
  - For items that will be washed, stitch after adhering
  - For best results, use Acid-Free Permanent Adhesive
- If your rollers pick up adhesive after use, clean with isopropanol alcohol.
- Store your machine and cartridge between 40° and 70° F.

## Basic Operation as easy as 1-2-3!




### Step One

Place item on feed tray.



### Step Two

Guide item forward while slowly turning handle clockwise until it comes out the back of the machine. Tear paper backing by pulling up against built in cutter.



### Step Three

Burnish or rub well around your item, peel from paper backing and adhere to project.