



Xyron® Tape Runner



User Guide


Unstoppable hold.

Contents

Features _____	04
Product Overview _____	05
How to Use _____	06
Cartridge Guide _____	07
How to Unload/Load Cartridge _____	08
Helpful Tips _____	10


Features

Targeted adhesive applicator.




Stay clean.

Apply permanent dot matrix adhesive without the gummy mess.



Change fast.

Easily refill in seconds with drop-in cartridges.



Be efficient.

Super handy size and accurate applicator puts you in total control.

Product Overview

front and underneath



Protective cap



Button access to
cartridge

How to Use

Preloaded with 40 feet of permanent adhesive.



1 Position.

Pull down protective cap to expose and position the adhesive tip to item surface.



2 Press.

Press down to apply even pressure.



3 Pull.

Slowly pull to run a strip of adhesive.

Cartridge Guide

Xyron® Tape Runner accepts 3/8" cartridges.



Permanent Adhesive

Apply for a secure, reliable bond.

#3302-12-32

Acid-free. Non-Toxic. Cartridges sold separately.

How to Unload/Load Cartridge



1 Open cartridge compartment by pushing button and lifting the lid.



2 Pull cartridge up and out of the applicator.



3 Drop the cartridge into the applicator.



4 Close the lid by pressing down until it clicks into position.

Making made easy.

Helpful Tips

General Tips:

- Our runner requires a slower motion to ensure the dots have enough time to release from the plastic liner.
- Keep adhesive tip level and apply even pressure for a full strip of adhesive.
- Store your applicator and cartridges in a cool, dry place.
- Use a variety of materials: paper, cardstock, vellum, fabric, ribbon, twine, craft foam, tissue paper, buttons, photos, paper flowers, and newspaper.
- Remove excess adhesive with your finger or Xyron® Adhesive Eraser (sold separately).

Fabric Tips:

- Wash sizing from fabric.



www.xyron.com

